

Installation Manual

Compatible Model	CToyota CHighlander
Year	2015-2021




1. Points to note

- For safety and to ensure the proper use of product, please ask a professional technician to install. Do not disassemble and install it privately in case of damaging product and installation accidents.
- Please arrange each wiring harness according to the wiring method in this manual, be sure to tie each wiring harness to the vehicle's original wiring harness with cable ties. Make sure the wiring harnesses are not located at the buckles or screw holes to avoid the wiring harnesses crushed by the vehicle interior trim panel buckles and screws during the installation process.
- Because some of the wiring harness terminals (as shown in the red ellipses below) are not inserted into the wiring harness connectors during manufacture, please insert terminals into the wiring harness connector first to avoid short circuit between terminals after the wiring harnesses have been arranged, then connect other plugs of the wiring harnesses (as shown in the blue ellipses below) with the original plugs.



- Check the function display of instrument panel before installation, whether the button of the vehicle is working properly, whether the doors and windows work properly while opening and closing, whether there are scratches on the internal and external surfaces of the vehicle; and report to the customers in a timely manner if there are any problems.
- During the process of disassembly and assembly, do not carry metal ornaments and other hard objects with you to prevent damage to the paintwork, seats and interior. Be sure to place the removed trim components properly to avoid scratching them.
- All the pictures in this manual are for reference only. Vehicle models with different configurations may have different pictures, but the installation methods are the same.

2. Installation tools



3. Product list

No.	Name	QTY	Picture
①	Strut	2	
②	ECU	1 set	
③	Wiring harness	1 set	
④	Power latch	1	
⑤	Added tailgate switch	1	
⑥	Other parts (screws, brackets, etc.)	1 set	Omitted



1. Remove the front left side trim panel and door sill panels.



2. Remove the rear left side door sill panel.



3. Remove the tailgate trim panels.



4. Remove the trim panel on the left side of the trunk (there are screws in the circle).



5. Remove the original latch and install the power latch.



6. Connect lock signal harness to the plugs of the power latch.




7. Connect the lock signal harness to the plugs of the original tailgate switch.




8. Install the added tailgate switch at the tailgate handle.



9. Remove the gas struts.



10. Replace the left and right body brackets.



11. Install the electric struts, L on the left and R on the right (the first letter of the strut code).



12. Use a φ21mm drill bit to drill a hole at the indicated position of tailgate. Both sides are the same.




13. Route the strut wiring harnesses.



14. Plug the left and right holes with rubber plugs.













15. Route the power harness to the tailgate (do not connect power before inserting terminals into the wiring harness connector).



Note: For models with fewer than 10 wires, just insert them according to the corresponding label or color.

16. Insert the power harness terminals into the wiring harness connector as shown above.

 <p>Power supply Signal connection</p>			 <p>Install the front switch here</p>	
<p>17. Route the power harness.</p>	<p>18. Ground at the left side of the tailgate.</p>	<p>19. Connect the power harness to the signal plug and its socket beside the rest pedal.</p>	<p>20. Remove the blank button from the switch panel and install the front tailgate switch.</p>	<p>21. The location of constant power fuse slot is indicated above (fourth in the first row).</p>
 <p>Wire points to the right</p>	 <p>Secure it with a nut</p>			
<p>22. Move the constant power fuse from the fuse box to the fuse tap, and then plug the fuse tap into the fuse box.</p> <p>5. System initialization method</p> <ol style="list-style-type: none"> 1. Press the added tailgate switch button to make the tailgate close automatically; 2. Press the switch button outside the tailgate to open the tailgate and will make a long sound of "beep". 3. The system initialization is complete. <p>6. Instructions for the electric tailgate</p> <p>1. Methods to open and close the tailgate:</p> <ul style="list-style-type: none"> ● Press the unlock button on the remote key 3 times; ● Press the unlock button at the driver's area 3 times; ● Press the original tailgate switch button to open; ● Press the added tailgate switch button to close; ● Press the added front switch button: press and hold for 4s to open. 	<p>23. Fix the ECU bracket to the indicated hole on the right side of the tailgate.</p> <p>2. Method to pause the tailgate: During the operation of the tailgate, press the button with any of the above methods, and the tailgate will be paused. Press again, and the tailgate will move in reverse.</p> <p>3. Method to memorize the height: Open the tailgate to the height you want to set, long press the added tailgate switch, and release the switch after hearing a long "beep ----". The height memory is complete. Tip: During the operation of the tailgate, pause the tailgate, and then push the tailgate to the ideal height with your hand.</p> <p>4. Meanings of the buzzer sound: "Beep" once: Receiving an open/close or pause signal, the tailgate will immediately open/close or pause; "Beep" twice: The tailgate has been fully opened or closed; "Beep" three times: The resistance during opening or closing the tailgate is too large, and the intelligent anti-pinch has been turned on; Long sound of "beep": The height memory is complete.</p>	<p>24. Insert the strut wiring harnesses ① ②, lock signal harness ③, and power harness ④ into the ECU in sequence and then mount the ECU on its bracket.</p>	<p>25. Initialize the system once, and then test each function of the electric tailgate.</p>	<p>26. Reinstall all the trim panels.</p>