

lecoco

Multi-Functional Bicycle

Designed by Lecoco

lecoco

Product Information

Product Name: Multi-Functional Bicycle

Model: C150

Recommended Age: 2-6

Headset: 28mm

Max Weight: 40kg

Max Load Capacity: 15kg

Material: Steel

Color: Black

Product Description: This is a multi-functional bicycle designed for children aged 2-6. It features a unique design that allows it to be used in three different modes: a standard bicycle, a balance bike, and a pusher. The bicycle is made of high-quality steel and is equipped with safety features such as a front and rear fender, a rear rack, and a rear light. The product is designed to be durable and long-lasting, providing a safe and enjoyable riding experience for children.

Front Wheel Mounting

1. Insert the front wheel into the fork.

2. Tighten the axle nut.

3. Check the wheel alignment.

Front Wheel Mounting

1. Insert the front wheel into the fork.

2. Tighten the axle nut.

3. Check the wheel alignment.

Epicride View Diagram

1. Standard Bicycle Mode

2. Balance Bike Mode

3. Pusher Mode

Features

- Adjustable Seat Height
- Removable Front Fender
- Adjustable Handlebar
- Removable Rear Fender
- Adjustable Rear Light
- Removable Rear Rack

Fender Installation

1. Attach the front fender to the front fork.

2. Attach the rear fender to the rear rack.

Handlebar Installation & Frame Unfolding Instructions

1. Install the handlebar.

2. Adjust the handlebar height.

3. Fold the frame for storage.

Saddle & Training Wheel Installation

1. Adjust the saddle height.

2. Install the training wheels.

Pedal Installation

1. Attach the pedals to the crank arms.

2. Tighten the pedal nuts.

Push Handle/Training Wheel Installation

1. Attach the push handle.

2. Install the training wheels.

Folding the Bike Frame

1. Release the frame lock.

2. Fold the frame.

Brake Cable Adjustment/Pedal Installation/Removal

1. Adjust the brake cable.

2. Install or remove the pedals.

Saddle/Support Frame Installation & Removal

1. Install the saddle.

2. Install or remove the support frame.

Push Handle Installation/Removal

1. Install the push handle.

2. Remove the push handle.

Cup Holder/Push Handle Installation/Removal

1. Install the cup holder.

2. Install or remove the push handle.

Safety Warnings

- Balance Bike & Balance Trainer Mode: Ages 2-6.
- Always wear your seat belt.
- Do not ride on public roads, slippery or uneven surfaces, steep slopes, etc.
- Do not ride on wet surfaces.
- Do not ride on uneven surfaces.
- Do not ride on wet surfaces.
- Do not ride on uneven surfaces.

Maintenance Instructions

- Check the tire pressure regularly.
- Check the brake pads.
- Check the chain.
- Check the wheels.
- Check the handlebars.
- Check the seat.
- Check the lights.
- Check the fenders.
- Check the rack.
- Check the push handle.
- Check the training wheels.

Specifications

Product Name: Multi-Functional Bicycle

Model: C150

Recommended Age: 2-6

Headset: 28mm

Max Weight: 40kg

Max Load Capacity: 15kg

Material: Steel

Color: Black

Diagram 1

Diagram 2

Diagram 3

Diagram 4

Diagram 5

Diagram 6

Diagram 7

Diagram 8

Diagram 9

Diagram 10

Diagram 11

Diagram 12

Diagram 13

Diagram 14

Diagram 15

Diagram 16

Diagram 17

Diagram 18

Diagram 19

Diagram 20

Diagram 21

Diagram 22

Diagram 23

Diagram 24

Diagram 25

Diagram 26

Diagram 27

Diagram 28

Diagram 29

Diagram 30

Diagram 31

Diagram 32

Diagram 33

Diagram 34

Diagram 35

Diagram 36

Diagram 37

Diagram 38

Diagram 39

Diagram 40

Diagram 41

Diagram 42

Diagram 43

Diagram 44

Diagram 45

Diagram 46

Diagram 47

Diagram 48

Diagram 49

Diagram 50

Diagram 51

Diagram 52

Diagram 53

Diagram 54

Diagram 55

Diagram 56

Diagram 57

Diagram 58

Diagram 59

Diagram 60

Diagram 61

Diagram 62

Diagram 63

Diagram 64

Diagram 65

Diagram 66

Diagram 67

Diagram 68

Diagram 69