

底面

封面

Cautions

- 1.No long-term placement in a low voltage state. Appliances do not use the electricity charge to more than 50% of storage, can be stored for more than 6 months, but in order to extend the service life, suggest charging every three months.
- 2.Do not modify or disassemble the appliance.
- 3.Do not reverse connect the input or output.
- 4.Be careful not to let the children touch appliance.
- 5.Do not put the appliance into the fire.
- 6.Please use qualified charger to charge the appliance.
- 7.Do not impact heavy and throw the appliance.
- 8.If there is any abnormal or malfunction when charging please contact your dealer.

Contact us

For any inquiries or comments concerning our product or any quality-related issue with our product, [or you want to customize any other battery packs](#), please feel free to contact us, we will respond to you as soon as possible and do our best to help you.

Email us: rome_jia@yabopower.com

Website: www.yabopower.com



YABO WP3200

User manual IP67 Waterproof



Thank you for applying our portable power bank. Please read the user manual carefully and properly keep it for reference.

内页

Specification:

Model: WP3200

Capacity: 10.905V/7000mAh 76.335Wh

Input: DC 5521: 12.6V / 3A Max.

Output: DC (5521): 10.905V(12.6-9V) / 3A Max.

Size: 102*56*82mm / 4.02*2.2*3.23in

Weight: 387g/0.853Lb.

Output: (12.6-9V)/3A Max
Input: 12.6V/3A Max

LED indicator

Indicator switch

The switch only controls the indicator light,
it doesn't control the battery charging/discharging.



Detail



WP3200 Package Contents:

1x WP3200 Power bank | 1x DC5521 male power cable | 1x 12.6V 1A AC/DC charger.
1x Velcro straps

How to charge the power bank (Full charge time: about 2.5 hours)

1. Connect the AC-DC charger to the power socket(100-240V available)
2. Connect the power bank to the AC-DC charger .
3. The LED indicator of the AC-DC charger showing **Red** means the charging process is working. The LED indicator of the AC-DC charger showing **Green** means the charging process has completed or the charging circuit is open.
4. The LED indicator of the AC-DC charger will change from **Red** to **Green** while the power bank is charged with 95% of the full.
5. After the unit is fully charged, please remove the AC wall charger in time.
6. Full charge time (estimated)=Capacity of power bank / output current of charger



Red-Charging



Green-Full

The indicator of the battery will not light during charging.
You need to check the led indicator of the AC/DC charger. It show Red means charging process going. It show Green means charging process completed, the battery be fully charged.

Application:

Compatible with LED strip light products, CCTV Camera, IP Camera, Telescopes, LED Panel, Amplifier, Modem, Car DVR, Speaker, mobile phone, breast pump portable and most 12V devices, etc.