⊠ **RockTek**



※ Key functions may differ by app or region, Follow actual operation.

About Your Remote

LED Indicator & Pairing







4× 3 35



1.Insert the batteries.

2.Press and hold the HOME

and BACK buttons together for 3s until the Green LED flashes rapidly, then release.

- Success: Green LED stays on for 2s, then turns off.

- Failure: Exits automatically after 60s, green LED turns off. - Device Name: RemoteG20

Backlit Mode

(1) Button Control: Press the Backlit button to turn the remote control's backlight on or off. The default setting

is Off. (2) Auto-Off: When the backlight is on and no operation is performed for 5s, the backlight will turn off automatically. (3) Backlight: When the backlight is on, pressing any button on the remote control will light up the keys.

Learning Keys

The four buttons in the "TV" section support IR Learning. Once programmed, they only transmit Infrared (IR) signals. Learning Steps

(1) Enter Learning Mode: Press and hold wkey in the TV area for $5s \rightarrow Red LED$ stavs on.

(2) Start Learning: Press the learning key → Red LED flashes

- ★ Keep the two remotes about 2-3 cm apart.
- Success: Red LED flashes 3 times, then stays on.
- Failure: Red LED keeps flashing.

→ Press the target key (TV).

(3) Exit: Press any number key, or it will auto-exit after 10s of

no operation, saving the data.

(4) Clear Data: Press and hold

+

for 3s → Red LED flashes 3 times.

Sleep Mode & Wake-up

The RC45 remote enters standby mode if there is no operation

for 10s, and press any key to wake it up.

Low Battery Warning When the battery is low, pressing any button will cause the red LED to flash for 10s. Please replace the battery promptly.

Air Mouse Mode

(2) Mouse Left-Click: When Air Mouse is on, press the "OK" key to perform the left mouse button function. (3) Air Mouse Off: When Air Mouse is on, press the "Air Mouse" key again or press any of the "Up / Down / Left /

(1) Air Mouse On: Press the "Air Mouse" key to turn on.

*After reboot or wake-up from sleep, the Air Mouse is off by default. If turned on, it will automatically enter sleep mode after 1 min of inactivity.

Compatibility Notice

Right" kevs to turn it off.

Due to the wide variety of Google TV and STB brands and models, individual key functions may vary.

Warranty Info

Please contact your local distributor, agent, or retailer for the limited warranty terms of the RC45.

Specifications

Product Name: Wireless Voice Remote Brand/Model Name: RockTek/RC45 Battery: AAA x 2 (not included) Support: Google TV/STB

Control distance: <10M

Made in China

Manufacturer: RockTek Co., Ltd. Dimensions/Weight: 180×45×20mm/83g Talk & Control. All in One.

RockTek © RockTek Co., Ltd.
All Rights Reserved. This manual is for reference only. In case of differences, follow the actual operation.