
# **Grill** Instructions



Assembly instructions

Assembly msuuchons		
Illustration	Quantity	Description
Α	1	Lid handle
В	2	M6x15mm screw
С	1	Valve disc
D	2	M4x8mm bolt & nut
E	1	Lid
F	10	Screw washer
G	1	Cooking grid
Н	1	Chorcoal grid
1	1	Fire bowl
J	2	Handle
K	4	M6x15mm screw
L	3	M6x30mm screw
М	1	Valve disc
N	3	Leg caps
0	1	Ash tray
Р	2	Leg
Q	1	Leg with cap
R	1	Bottom shelf
S	2	Wheel
Т	2	M8 mother



- 1. Place the leg caps N on the legs P and Q and screw them to the fire bowl I using the screws L
- 2. Hook the shelf R between the legs P and Q, attach the wheels S and fix them with the nuts T.
- 3. Mount the handles J to the fire bowl I with the screws K.
- 4. Screw the valve disk M to the bottom of the fire bowl I and insert the charcoal grid H.
- 5. Assemble the handle A to the cover E using the bolts and nuts B.
- 6. Attach valve disc C to cover E with bolt and nut D.
- 7. Insert the cooking grid G and close the lid.

# Purpose of use

The grill is intended for grilling suitable foods. It is designed for the quantities occurring in private households and is unsuitable for commercial purposes.

## Grill

#### Instructions

### <u>Use</u>

Before using the grill for the first time, clean it with warm water and a little washing-up liquid and dry it then turn it off. Open the lower ventilation valve. Please pile the charcoal on the Charcoal grate and ignite it with cardboard or commercially available kindling aids. The optimal ember state is Achieved when white ash forms on the charcoal. Then distribute the charcoal with a suitable tool evenly on the charcoal grate and place the grill grate on top.

Place your food to be grilled in the middle of the grill, close the hood and open the valve in the Lid. Only open the hood to turn, test or remove the food to be grilled. use safety gloves and, if necessary, grill tongs when grilling

Place your food to be grilled in the middle of the grill, close the hood and open the valve in the Lid. Only open the hood to turn, test or remove the food to be grilled. use safety gloves and, if necessary, grill tongs when grilling

## Safety instructions

- Do not use the grill in closed rooms
- Do not use the grill near flammable objects
- Only use the grill on a stable and level surface
- Do not touch the hot grill without protective gloves, risk of burns!
- Do not try to move the hot grill to another location
- Never leave the hot grill unattended
- Keep your grill away from children and animals
- Only empty the leftover charcoal when it has completely cooled down
- Only use grill lighters that comply with the EN 1860-3 standard, no petrol, spirits or
- Only use the grill for grilling food that requires such treatment
- Do not use pans, pots or similar that are unsuitable for use on the grill
- Only place the food to be grilled on the grate after the lighter has burned down completely and the coal has glowed through