

Cautions

- 1. The appliance should be taken to avoid exposure, percussion, water, and rain in the transport process, and make the battery positive and negative pole Insulation.
- 2. The appliance should be stored in a cool dry indoor storage, avoid flooding, rain.
- 3. No long-term placement in a low voltage state. Appliances do not use the electricity charge to more than 50% of storage, can be stored for more than 6 months, but in order to extend the service life, suggest charging every three months.
- 4. Do not immerse the appliance in water or become wet.
- 5. Do not modify or disassemble the appliance.
- 6. Do not reverse connect the input or output.
- 7. Be careful not to let the children touch appliance.
- 8. Do not put the appliance into the fire.
- 9. Please use qualified charger to charge the appliance.
- 10. Do not impact heavy and throw the appliance.
- 11. If the liquid of the appliance gets into your eyes, do not rub your eyes, rinse with water and consult doctors immediately.
- 12. If there is any abnormal or malfunction when charging please contact your dealer.


Contact us

For any inquiries or comments concerning our product or any quality-related issue with our product, [or you want to customize any other battery packs](#), please feel free to contact us, we will respond to you as soon as possible and do our best to help you.

Email us: [rome\\_jia@yabopower.com](mailto:rome_jia@yabopower.com)  
Website: [www.yabopower.com](http://www.yabopower.com)



YABO NB3200  
User manual



Thank you for applying our portable power bank. Please read the user manual carefully and properly keep it for reference.

Specification:


Capacity: 10.8V 6400mAh(19200mAh at 3.6V) 69.12Wh

Input:

USB-C: 30W Max.  
DC(5521): 12.6V/4.5A Max.


Output:

USB-A: 20W Max.  
USB-C: 5V/3A 9V/3A 12V/2.5A 15V/2A 20V/1.5A 30W Max.  
DC(5521): 10.8V(12.6-9V)/4.5A Max.  
Size: 160x82x22mm




Two charging methods

1.DC port: AC/DC12.6V charger



2.USB-C port: USB wall charger



How to charge the power bank?

- 1: It can be charged via the DC port using the 12.6V AC/DC wall charger.
- 2: It can be charged via the USB-C port using the AC/DC wall charger.
- 3: It can be charged via the DC port using the 18V Solar panels.

The led indicator of AC-DC charger show RED means charging process going.  
The led indicator of AC-DC charger show GREEN means charging process completed.  
After the unit is fully charged, please remove the AC wall charger in time.

Package content :

- 1x Power Bank
- 1x 12.6V/1A AC/DC Charger
- 1x USB-C to USB-C Cable
- 1x DC5521 1 female to 2 male power splitter Cable

