

PIPE & WALL INSPECTION SYSTEMS



INSTALLATION GUIDE & MANUAL


Read these instructions completely before operating this device

PIPE & WALL INSPECTION SYSTEMS

Inventory



Monitor



Winding wheel



Aluminum box



Universal camera



Charger



Centering device

1.Specification parameter

Display	
Display size	7 inch LCD
Screen display scale	16:9
Best resolution	800×600
Menu language	Chinese, English and other 9 languages available
Video input	AV1 (1 Vp-p / 75 AV2); blue screen, no signal

Plugged	
Adapter	110~240VAC 50/60Hz; 12 VDC /1000mA
Lithium battery	12V 4500mAH
Power	35W (maximum)
Charging interval	5-6 hour
Working hours	5-6 hour
Camera	
Viewing range	120 degree
Lamp	8 white LED lights
Temperature	-20°F ~ 120°F (-28°C ~ 50°C)
Shell material	AluminumV
PAL system output NTSC system output	720X576(PAL) 720X480(NTSC)
Waterproof grade	IP68
Coil	
Cable diameter: Ø 4.8mm	
Cable length : 20m 30m 40 m	

2. Product introduction

2.1 Camera

- 1) White LED light (8 stars)
- 2) Optical explosion proof glass cover
- 3) Stainless shell



2.2 Cable rack





2.3 Display screen

MONITOR WITHOUT DVR



MONITOR WITH DVR



- 1) PUSH BUTTON
- 2) ON/OFF AND LED LIGHT OF CAMERA ADJUSTING KNOB
- 3) MIRROR
- 4) VOLUME -
- 5) POWER
- 6) MENU
- 7) VOLUME +
- 8) BATTERY ELECTRIC POWER DISPLAY
- 9) UP
- 10) RIGHT
- 11) OK
- 12) DOWN

- 13) LEFT
- 14) STOP
- 15) PLAY/PAUSE
- 16) MENU
- 17) ESC
- 18) 7" TFT SCREEN
- 19) SUN SHIELD
- 20) SD CARD SOCKET
- 21) EARPHONE SOCKET
- 22) DC 12V SOCKET
- 23) IMPERIAL SYSTEM/METRIC SYSTEM SELECTION
- 24) RESET

3. Control panel operation instructions

3.1 How to operate the sun shield

Press the push button (1) to open the sun shield (19) when you want to use this monitor.

Press the push button (1) first, then press the sun shield (19) cover to close the sun shield.

3.2 Connect the camera head with the cable, first Turn on this unit by turning on the adjusting knob (2), also by adjusting this knob (2) to adjust the LED light brightness of camera.

3.3 Control panel operation instructions for monitor and DVR function

By pressing the button (3)(4)(5)(6)(7)(8) to operate the monitor function

By pressing the button (9)(10)(11)(12)(13)(14)(15)(16)(17) to operate the DVR function

Features:

1. MPEG-4 video compression
2. D1(704*576) resolution
3. MPEG-4/ASF video format, MP3 audio format
4. Real-time stamp on videos, overwrite
5. Manual/motion detect/scheduled/power-up record
6. Audio input, audio compression 8KHZ/ADPCM
7. 5/15/30fps optional
8. SDHC memory support, up to 128GB
9. TV-out enables better resolution by TV set
10. MPEG-4/ASF playback
11. AV-IN, AV-OUT directly connect with camera, TV, monitor
12. Support IR remote operation, built-in ADC for external keyboards
13. Support manually snapshot, auto record by triggering port
14. Built-in RS232 series port, enables external remote, keyboard for operation and software set-up
15. 5-35V for wide power supply use
16. Low power-consumption, 1W when standby, 2W when recording
17. Electronic dog ensures normal working
18. Board dimension: 60*45mm, net weight 100g, with position holes for different expandable use











1.Features

This product uses the most advanced image processing technology to make the output image quality lossless, whether it is in the preview it is almost equal to the original image quality when the video is played back, which solves the problem that many users use analog cameras as in-put The image quality is seriously degraded after DVR processing. At the same time, we use H265+MP4 video technology to make Video files are smaller in size and have a wider application range, and video files can be played back on various multimedia devices.

Product Features

- Support NTSC PAL camera
- Support H264 H265 image compression technology
- Support up to 128 SD card
- Support snap during video recording
- Support SD card upgrade firmware
- Support remote control operation
- Multi-language support Chinese, English, German, Spanish, Polish, French
- Support MP4 video file format
- Support power failure protection function

1.3 remote control

button	Operation introduction
	Video button
	Menu button
	Up buttons
	down buttons
	right buttons
	Left buttons
	Confirm button
	return key
	Play button
	Stop button


! Tips:



In the process of equipment recording, or in the real-time picture state, press the PLAY button
Can directly enter the playback file



During video playback, press the left and right buttons to fast forward and rewind



During the playback of the video, press the up and down keys to automatically jump to the next video
Or the previous video, which is convenient and quick.

2. Software icon description

2.1 Menu image interface

current time



Audio icon



N(NTSC) P (PAL)




SD card display icon



U disk display icon




This icon indicates failure



Recording time period

This icon represents the SD card has been read



Recording time period

This icon represents the SD card has been read

After the device reads the card, press the remote control



The lower left corner of the screen during recording



00:25:59

Flashing

If you want to stop recording, click the





button

2.2 Menu playback interface



Tip: In the file list state,
Press the key STOP to delete the current file



1. "MENU" button on the remote controlCan enter directly
Menu page to operate
2. Click the OK button on the remote controlCan enter the play folder
3. Click the OK button on the remote controlEnter video playback
The list can be in accordance with the time periodChoose the video you
want to play
4. Enter the current playback video interface

We have added shortcut keys during video playback

Preview image

1. Press **OK** to record directly
2. Press the **▲** button to take a photo
3. Press the **PLAY** key to enter directly Playback video interface **ESC** return


In playback mode

1. Press **▲** to play the previous video
2. Press **▼** to play the next video
3. Press **◀ ▶** to fast forward and rewind


2.3 Picture playback



1. Press **▲** to take a photo
File will be stored on SD card
Inside the picture folder





2. Press the remote **MENU** button
Enter the menu Select picture playback





3. Press the remote **OK** button
Enter the picture folder

3.System settings

3.1 System settings




1. Press the remote  button
Enter the menu



key to select system settings

key to enter





language settings: Include Chinese/English/German/Spain/Polish/French

Factory settings: This option can be used to restore the factory default settings(operate with caution)

system version: This setting is to view the system software version number

3.2 OSD settings





Preview :In the real-time preview stateNo watermark on the screen.

Replay :Refers to the playback of video or picturesNo watermark

video : Video file watermark off

picture: Picture file watermark off

3.3 Save settings/format



Storage settings:
you can view storage usage
Capacity and remaining capacity.

If the device cannot be displayed
Storage status,
Available through this function
Format the storage device.



Fault judgment

Can't read card and can't record video?

1. Please use a genuine card.
2. If the card is not read, enter "Save Settings" to format
3. For SD cards that have not been used for a long time, please clean the pins of the SD card before inserting it into the device.
4. The card is not read, please restart the device.

4. Image settings





Image setting:
through color contrast
Brightness adjusts image
parameters in real time.



Mirror settings:

After entering the image settings ,
the remote control ◀ ▶ key to select
enable or disable, then press **ESC**
key it can be automatically saved.


Chroma: refers to adjusting the brightness of the screen on the screen to high or low



Color saturation: refers to adjusting the color of the screen picture to dark or light


Contrast: A measure of comparison between the bright and dark parts of the same picture. The contrast is large, and the picture is very bright in black and white.





5.Video settings

5.1 Recording time/segment setting



Remote control  key to enter the menuSelect "Video Settings"  button to enter



Video packaging time:
Press  to pop up the option bar,
then press  to select

If you want the time period,
press  to confirm and save.

Video packaging time: After this function option bar is expanded, 1/5/10/15/30/60 minutes and other time periods, After the settings are saved, the device packs the video files according to this time period, For example: set to 1 minute, then the device will save the video as a video file per 1 minute when recording

5.2 Video frame rate

Video frame rate: low frame rate video, the advantage of saving storage space, if not necessary, you can press the default setting.

VIDEO SETTING	
VIDEO CLIP TIME	1 MINUTE
FRAME RATL	NTSC30FPS/PAL25FPS
VIDEO QUALITY	NTSC30FPS/PAL25FPS
COMPRESS	15FPS 5FPS
PHOTO QUALITY	HIGH
RECORD MODE	MANUAL
OVERWRITE	ON
TV SYSTEM	PAL

Video frame rate:

Press **OK** to pop up the option bar,

then press  to select

If you want the time period,

press **OK** to confirm and save.

5.2 Video quality

VIDEO SETTING	
VIDEO CLIP TIME	1 MINUTE
FRAME RATL	NTSC30FPS/PAL25FPS
VIDEO QUALITY	HIGH
COMPRESS	HIGH MIDDL LOW
PHOTO QUALITY	LOW
RECORD MODE	MANUAL
OVERWRITE	ON
TV SYSTEM	PAL

Video quality:
High/medium/
low, three modes

5.3 Video compression format

VIDEO SETTING	
VIDEO CLIP TIME	1 MINUTE
FRAME RATL	NTSC30FPS/PAL25FPS
VIDEO QUALITY	HIGH
COMPRESS	H. 264
PHOTO QUALITY	H. 264 H. 265
RECORD MODE	MANUAL
OVERWRITE	ON
TV SYSTEM	PAL

Video compression method:
H.264/
H.265 two compression
methods

5.3 Picture quality

High/medium/low, three modes, the higher the picture quality, the clearer the picture.

VIDEO SETTING	
VIDEO CLIP TIME	1 MINUTE
FRAME RATE	NTSC30FPS/PAL25FPS
VIDEO QUALITY	HIGH
COMPRESS	H. 264
PHOTO QUALITY	HIGH
RECORD MODE	HIGH
OVERWRITE	MIDDLE
TV SYSTEM	LOW
	PAL

Picture quality:
High/medium/low, three modes

5.4 Video settings

VIDEO SETTING	
VIDEO CLIP TIME	1 MINUTE
FRAME RATE	NTSC30FPS/PAL25FPS
VIDEO QUALITY	HIGH
COMPRESS	H. 264
PHOTO QUALITY	HIGH
RECORD MODE	MANUAL
OVERWRITE	MANUAL
TV SYSTEM	POWER UP
	PAL

Video mode:
Manual recording/automatic recording:
Set up manual recording
Need to use buttons, etc.
Power-on video: when the device is turned on
Automatically record

5.5 Loop recording settings

VIDEO SETTING	
VIDEO CLIP TIME	1 MINUTE
FRAME RATE	NTSC30FPS/PAL25FPS
VIDEO QUALITY	HIGH
COMPRESS	H. 264
PHOTO QUALITY	HIGH
RECORD MODE	MANUAL
OVERWRITE	ON
TV SYSTEM	ON
	OFF

Video coverage: refers to the automatic
Loop, if closed, after the device is fullAutomatically stop, it is recommended to turn on (default is on status)

DISPOSAL INSTRUCTION

Disposal of the packaging

- Please make reference to the guidelines and standards for appropriate disposal of the packaging valid in your region. In part, the package may consist of plastic bags - watch this respect, with special care to ensure that this is not out of the reach of children. There is a risk of suffocation!

Disposal of waste equipment

- Equipment must be disposed of in accordance with the rules and regulations of the local waste disposal.



Meaning of the "dustbin"

Protect our environment; electrical appliances do not belong in household waste. Use the provided for the disposal of electrical equipment collection points and enter your electrical and electronic equipment that you no longer use. They help ensure that the potential effects of incorrect disposal on the environment and human health to be avoided. So do your part to recycle, recycling and other forms of recovery of waste electrical and electronic equipment. Information on where the devices are disposed of, please contact your local authorities or local Governments.

Parameters Table

System language	Include Chinese/English/German/Spain/Polish/French
AV input	CVBS NTSC PAL
data storage	SD card (support up to 128G)
voltage range	Input 12V
Play video jump	press the up and down keys to jump to the next video
Video mode	automatic / manual
Video standard	CVBS
Video format	MP4
Playback software	VLC media pLayer/WINAMP
Operating temperature	-20° ~+60°
Control Method	button
Snap an image	Support to capture pictures during recording
Watermark	Support watermark off
reset	support
Automatic coverage	Optional whether to be overwritten
Mirror settings	Support mirror setting
Image adjustment	Support image adjustment
Fastforwardandrewind	support

